CVS Hemodynamics

Faisal I. Mohammed, MD, PhD.

Objectives

✓ point out the physical characteristics of the circulation:

distribution of blood volume total cross sectional area velocity blood pressure

- ✓ List the determinants of blood flow
- ✓ Define and calculate blood flow, resistance, and pressure
- ✓ Define and calculate conductance
- ✓ Apply Poiseulle's law

Resource: Guyton's textbook of medical Physiology

BLOOD FLOW THROUGH BODY TISSUES IS INVOLVED IN:

• Delivery of O2 and removal of CO2 from tissue cells.

• Gas exchange in lungs.

• Absorption of nutrients from GIT.

• Urine formation in kidneys.

The Circulatory System



The Capillaries



Blood Volume Distribution



The Circulatory System is Composed of the Systemic and Cardiopulmonary Circulation

• Systemic Circulation

- Serves all tissues except the lungs
- Contains 84% of blood volume
- Also called the *peripheral circulation*
- Pulmonary Circulation
 - Serves the lungs
 - Lungs contain 9% of blood volume and heart 7%

Blood Reservoir Function of Veins

- More than 60% of blood is in veins
- Under various physiological conditions, blood is transferred into arterial system to maintain arterial pressure.
- The spleen, liver, large abdominal veins, and the venous plexus also serve as reservoirs.
- Spleen also serves as a special reservoir for red blood cells.

Basic Theory of Circulatory Function

- *Blood flow* to tissues is controlled in relation to tissue needs.
- *Cardiac output* is mainly controlled by local tissue flow.
- *Arterial pressure* is controlled independent of either local blood flow control or cardiac output control.

Pressure Changes through the circulation



Blood Pressure Profile in the Circulatory System



- High pressures in the arterial tree
- Low pressures in the venous side of the circulation
- Large pressure drop across the arteriolar-capillary junction

Changes in Cross Sectional Area and Velocity



The Capillaries Have the Largest Total Cross-sectional Area of the Circulation

ст
2.5
20
40
2500
250
80
8

Velocity of Blood Flow is Greatest in the Aorta

Velocity of Blood Flow = Blood Flow Cross sectional area Flow= A*V A= Area , V= Velocity

Aorta >Arterioles> Small veins >Capillaries

BLOOD FLOW

 Blood flow or "F" = Blood flow means simply the quantity of blood that passes a given point in the circulation in a given period of time (mL/Sec).



In the systemic circulation

*(F) = cardiac output (CO),

* the pressure gradient = (difference between mean arterial blood pressure and atrial pressure which is around zero) = mean systemic arterial B.P.



1) Pressure gradient produced by heart pumping moves blood in the system from the arterial to the venous side, 5 l/min

2) Fluid pressure expands cardiac chambers and blood vessels.

CO(F) = mean systemic arterial blood pressure total peripheral resistance



 Velocity (V) is proportionate to flow (F) divided by cross sectional area of the blood vessel (A): F=A*V



So blood flow is fastest in aorta and slowest in capillaries ?

LAMINAR VS. TURBULENT FLOW

Blood does not flow as a plug in *large* vessels.



How does it flow ?

Laminar flow: Definition:



□ The fluid nearest the vessel wall flows the slowest, and fluid in the center of the tube moves the most rapidly.

□This produces layers (*'laminae'*) with uniform speeds at certain distances from the wall.

□If the flow rate is increased then the trend for turbulence will increase .

Blood Flow

- *Blood flow* is the quantity of blood that passes a given point in the circulation in a given period of time.
- *Unit of blood* flow is usually expressed as milliliters (ml) or Liters (L) per minute.
- Overall flow in the circulation of an adult is 5 liters/min which is the *cardiac output*.



Blood Vessel

Characteristics of Blood Flow

- Blood usually flows in streamlines with each layer of blood remaining the same distance from the wall, this type of flow is called *laminar flow*.
 - When laminar flow occurs, the velocity of blood in the center of the vessel is greater than that toward the outer edge creating a parabolic profile.



Blood Vessel

Turbulent flow: Definition

 $v.d.\rho$

Reynold's No (Re) =

If Re is > 400 then Turbulent flow



Pressure Gradient

Laminar Vs. Turbulent Blood Flow

Causes of turbulent blood flow:

- high velocities
- sharp turns in the circulation
- rough surfaces in the circulation
- rapid narrowing of blood vessels



- Laminar flow is silent, whereas turbulent flow tend to cause *murmurs*.
- Murmurs or *bruits* are important in diagnosing vessels stenosis, vessel shunts, and cardiac valvular lesions.

Clinical significance of turbulence?

• Normally : at the branching of vessels and at roots of aorta and pulmonary arteries .

- Pathologically:
- 1. Constriction of arteries by atherosclerotic plaque.
- 2. In severe anemia.
- 3. Stenotic and incompetent cardiac valves.

The peripheral resistance:

• It is the resistance to blood flow through a vessel caused by friction between the moving fluid and the vascular wall.

 Most of the resistance to blood flow occurs in arterioles (50%)- they called resistance vessels, and capillaries (25%) so it is called peripheral.

Thank You



Hemodynamic laws

```
• Ohm's law: F = \Delta P/R
```

```
• F = Flow, \Delta P = Change in Pressure,
```

```
\mathbf{R} = \mathbf{Resistance}
```

$$CO = \frac{MAP - Rt.AtrialP}{TPR}$$

CO = cardiac output, MAP = mean arterial pressure, TPR = total peripheral resistance. Since Rt. Atrial pressure = 0 then MAP

$$CO = \frac{MAT}{TPR}$$

Hemodynamic laws... cont

• Poiseuille's law

 $F = \pi \Delta P r^4 / 8\eta L$ F = flow, $\Delta P = change in pressure$ r = radius of the vessel $\eta (eta) = viscosity$ L = length of the vesselThen Resistance, $R = 8\eta L / \pi r^4$

Effect of Vessel Diameter on Blood Flow



Parallel and Serial Resistance Sites in the Circulation

$$R_{total} = R_1 + R_2 + R_3 + R_4 \dots$$



$$\frac{1}{R_{\text{total}}} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \frac{1}{R_4} \dots$$